


Tellur Mithra



TLL161121

Instruction Manual

TWS Bluetooth Speaker

A. Appearance



1. **Mic:** Microphone for Hands-free calling
2.  Long press and hold  for 2 seconds to turn on the device, automatically enter into Bluetooth searching. The blue light will flash and play the sound "Bluetooth device is ready to pair". The Bluetooth light will stop flashing and keep stable after pair and connect another device by Bluetooth. Short press to answer when you have an incoming call, and short press again to end up the call.
3. Lithium battery power display
4. Mood light button: Short press the button to turn on or off the mood light.

TWS: Long press the mood light button of two Mithra speakers at the same time, the two Mithra will pair as TWS Speakers.

5. DC 5V Power supply

B. Input / Output

1. DC 5V Power supply
2. Built in Li-polymer battery 800mAh
3. Power output: 5W

C. Charging use

Lithium battery charging: The light will bright in red after the USB cable is inserted for charging, and the red light turns off after the Lithium Battery is fully charged




Disposal and recycling information

The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage. It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws. Proper collection and recycling of your

equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment.



ABN Systems International

-  Str. Marinariilor, nr.29
Sector 1, Bucuresti, Romania
-  004.021.233.09.95
-  office@tellur.com
office@abnsystems.ro
-  www.tellur.com