

Tellur Apollo



Bluetooth Portable Speaker User Manual

INTO YOUR FUTURE


What 's in the box

Speaker unit	Micro USB & AUX cables	Manual

Main features and functions

Portable Bluetooth speaker
 Supports iPhone, iPad and any music devices with Bluetooth
 Supports Micro SD (TF) card playing
 AUX function, supports MP3/PC/mobile phones
 Vol+/Vol-/Next/Prev/Play/Pause/Mode/Pairing buttons
 Output: 10W*2
 Bluetooth V4.1
 Supports A2DP, AVRCP
 Frequency: 80HZ-20KHZ
 Distance: >10 M
 Power input: DC 5V

Product diagram



1. Volume down
2. Volume up
3. Bluetooth pairing/Mode button
4. Power/Play/Pause button
5. Previous track
6. Next track
7. Power indicator

8. Micro USB charging port
9. AUX-IN jack
10. Micro SD (TF) card port

Operating instructions

Power ON /Off the speaker:

1. Press and hold the power button on the speaker to power On or Off.

Pairing your mobile Bluetooth device to the speaker:

Pairing instructions may differ depending on the device you are using. Please refer to your device's user manual for further information.

1. Pairing

- a. Make sure that your mobile device is within 1 meter of the speaker when trying to pair and that the speaker is powered on and in Bluetooth mode.
- b. If the speaker hasn't been connected to any mobile device, it will enter pairing mode automatically. If the speaker has been connected, press and hold the Pairing button for 3 seconds until Bluetooth speaker enters pairing mode. The LED indicator will flash rapidly when the speaker enters pairing mode.
- c. Access the Bluetooth settings on your mobile device and select Search/S can for devices. Your mobile device will begin to search for a Bluetooth signal.
- d. You will see the name "Tellur Apollo" appear in the device list. Select it to pair.
- e. After a successful connection has been made, the Bluetooth LED indicator will light up.

2. Reconnecting

- a. The speaker will automatically connect to the last Bluetooth device that was paired when powered on.
- b. If the speaker does not automatically reconnect, make sure that your mobile device is within 1 meter of the speaker, access the Bluetooth settings on your mobile device and start the pairing steps from the beginning, as first connection.

Playing music:

1. Make sure that your Bluetooth A2DP (audio/music) mobile device is connected with the speaker.
2. Turn on the music from your mobile device or simply press the Play/Pause button and you should hear the music playing through the speaker. If the music is low, increase the volume on the speaker first, then adjust your mobile device's volume.
3. You can control the playing directly from the speaker:
 - a. Previous track - press the "Previous track" button;
 - b. Next track - press the "Next track" button;
 - c. Increase volume - press the "+" button;
 - d. Decrease volume- press the "-" button;
 - e. Play/Pause switch - press the Play/Pause button.

AUX function

1. Turn on the speaker.
2. Connect the speaker to a music player such as MP3 or mobile phone through 3.5mm AUX cable.
3. The speaker will enter AUX mode and play the music from the player through AUX. If the speaker does not enter AUX mode automatically, press the Mode button to switch into AUX mode.

Micro SD card playing

1. Turn on the speaker.
2. Put the Micro SD card into the Micro SD slot and the speaker will play the music from the Micro SD card. If the speaker does not enter the Micro SD mode automatically, press the Mode button to select the Micro SD mode.

Charging the speaker

Attach the small end of the Micro USB cable to the Micro USB charging port on the back of the speaker and attach the larger end to your computer/USB adapter/charging device (5V). The charging LED indicator will turn red while charging and it will turn off when the charging is complete.

Read carefully and keep this manual

Caution: Any changes or modifications not expressly approved could turn the equipment inoperable.

If you have any questions or need help for this equipment, please contact the supplier or service center, do not intervene yourself.

Disposal and recycling information

The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage. It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of electrical and electronic equipment waste (WEEE) and batteries according to local laws. Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment. Improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment.

